



PETRI PLATE: - A petri plate consists of a bottom dish postion and a large top postion as the lid. The dish unitains the medium and the lid seves as a lose way. For soutine microbial cultivation, dishes 80mm, 90mm, 100 mm and 150 mm in diameter.

PIPPETTE: The glass-made pipette are used in the laboratory as transfer instruments. They are calibrated to deliver different volumes depending on experimental requirements the pipette are available in different measuring capacities, such as 0.1 ml, 1.0 ml, 5.0 ml, and 10.0 ml.

REAGENT BOTTLE: The reagent bottles has ground glass or plastic Stoppers and are made of different sizes.

TEST TUBES: - Test tubes of varying sizes are used in laboratory for a variety of purposes such as preparing slopes of agas media, performing various biochemical test dispensing different fluid media.





	Date
	。
15:	WATER BATH: A wally balk is an exembial
	apparatus in which water is healed upto required
	degrees of centigrade. The temperature, controlled by
	a Kermostot, con be raised upto 100°c.
16:	MIRE LOOP & NEEDLE: The wire loop and
	meedle are the instrument used for the transfer
	of mos from one ressel to another, from one median
	to mother such transfer is termed as subculturing
	or inoculation. The loop and needle are made from
	inest metals such as platinum. They are sterlized
200	by burning them in the blue portion of Bunsen.
	burner flome.
ang Maria Pa	Service of the servic
•	
.V.I.P	

